



Model No. SJ401 SCROLL SAW



Model No. SJ401 SCROLL SAW



Model No. SJ401 SCROLL SAW

Item	Parts No.	Description	I/C	Qty	N/O	Opt. 1	Opt. 2	Note
002	303209-000	HOSE		1				
003	303071-001	KNOB		1				
005	021200-001	SPRING WASHER		1				
006	021101-027	FLAT WASHER		1				
007	020613-001	HEX.SOCKET BOLT		1				
008	270310-000	BLADE SUPPORTER & GUARD		1				
009	021104-023	FLAT WASHER		1				
010	020601-003	HEX.SOCKET BOLT		1				
011	290081-000	DUST BLOWER		1				
012	021104-023	FLAT WASHER		1				
013	020601-003	HEX.SOCKET BOLT		1				
015	290079-000	SUPPORT ROD		1				
016	026104-001	PIN SPRINGR		1				
017	020601-003	HEX.SOCKET BOLT		1				
018	021104-023	FLAT WASHER		1				
019	270309-000	HOLD DOWN FOOT		1				
020	020505-003	SET SCREW		1				
021	225070-000	HOLD DOWN BLOCK		1				
022	303204-003	MOTOR REAR COVER		1				
C10	303205-001	BRUSH HOLDER		2				
023	050007-000	BEARING		1				
024	900312-000	FIELD ASS'Y WITH MOTOR HOUSING		1				
027	375009-001	CARBON BRUSH		2				
028	303000-001	BRUSH HOLDER CAP		2				
029	224053-000	TABLE		1				
030	021402-001	WAVE WASHER		1				
031	020614-001	SOCKET HEAD SCREW		1				
032	270311-000	TILT BRACKET		1				
033	021101-025	FLAT WASHER		1				
035	900403-000	LOCK HANDLE ASS'Y		1				
038	080181-001	POWER CORD		1				
039	020219-001	SCREW		3				
040	880084-000	ARMATURE ASS'Y WITH BEARINGS		1				
D10		INC. 23,41						
041	050015-100	BEARING		1				
042	225083-000	MOTOR FRONT COVER		1				
043	240051-000	BASE		1				
044	020103-015	SCREW		1				
045	913002-000	BUSHING		1				
046	913002-000	BUSHING		1				
047	020103-015	SCREW		1				
048	270248-000	BUSHING SET COVER		1				
049	302043-003	SWITCH CASE		1				
050	020103-015	SCREW		1				
053	863305-006	INDICATION LABEL		1				
054	022804-000	NUT		1				
055	290080-000	LOCK POST		1				
056	020228-001	SCREW		1				

Model No. SJ401 SCROLL SAW

Item	Parts No.	Description	I/C	Qty	N/O	Opt. 1	Opt. 2	Note
057	303259-001	SWITCH COVER		1				
058	021308-001	EXT.TOOTH WASHER		1				
059	020103-015	SCREW		1				
060	022301-001	NUT		1				
061	020103-015	SCREW		1				
062	020103-015	SCREW		1				
063	020228-001	SCREW		1				
065	303207-000	CONTROL KNOB		1				
067	370021-000	SWITCH,WASHER & NUT		1				
068	020726-001	PAN HEAD SCREW		1				
069	270249-000	POINTER		1				
071	021306-001	LOCK WASHER		1				
073	020103-015	SCREW		2				
074	021306-001	LOCK WASHER		1				
075	020720-003	SCREW & WASHER		2				
076	020720-003	SCREW & WASHER		2				
077	240042-000	COUNTERWEIGHT		1				
078	060047-000	SPACER		1				
079	020508-001	SET SCREW		1				
080	020723-007	SCREW & WASHER		3				
081	270308-000	PLATE COVER		1				
082	020106-013	SCREW		1				
083	024201-001	PULL NAIL		1				
084	024201-001	PULL NAIL		1				
085	303202-000	BLADE STORAGE CASE		1				
086	020106-013	SCREW		1				
087	020200-017	SCREW		2				
088	020200-017	SCREW		2				
089	900782-008	BOARD COVER ASSY (220V)		1				
090	900625-006	CONTROL BOARD ASS'Y (240V)		1				
091	225112-000	ARM COVER(LEFT)		1				
092	026202-007	PIN		1				
093	020702-001	COVER SET SCREW		1				
094	020702-001	COVER SET SCREW		1				
095	020702-001	COVER SET SCREW		1				
096	020702-001	COVER SET SCREW		1				
097	020702-001	COVER SET SCREW		1				
098	225111-000	ARM COVER(RIGHT)		1				
099	330026-000	AIR DIAPHRAGM		1				
100	020702-001	COVER SET SCREW		1				
101	020702-001	COVER SET SCREW		1				
102	020702-001	COVER SET SCREW		1				
103	225069-000	BLADE TENSION LEVER		1				
104	026104-009	PIN		1				
105	290078-000	TENSION ADJUSTING BOLT		1				
106	021100-011	FLAT WASHER		1				
108	029141-001	SPRING		1				
109	026103-015	ROLL PIN		1				

Model No. SJ401 SCROLL SAW

Item	Parts No.	Description	I/C	Qty	N/O	Opt. 1	Opt. 2	Note
110	020608-003	HEX. SOCKET BOLT		1				
111	250006-000	UPPER BLADE NUT		1				
112	029144-001	COMPRESSION SPRING		1				
113	250005-000	UPPER BLADE HOLDER		1				
114	250004-000	LOWER BLADE NUT		1				
115	026103-015	ROLL PIN		1				
116	029144-001	COMPRESSION SPRING		1				
117	250003-000	LOWER BLADE HOLDER		1				
118	026107-001	PIN		1				
119	020608-003	HEX. SOCKET BOLT		1				
120	026107-001	PIN		1				
121	225073-000	BLADE SUPPORT		1				
122	026102-007	PIN		1				
123	020600-001	HEX. SOCKET BOLT		1				
124	026103-015	ROLL PIN		1				
125	060052-000	SPACER		1				
126	303201-000	ARM LINK		1				
127	050012-000	BEARING		1				
128	270252-000	BEARING FENCE		1				
129	020200-015	SCREW		1				
130	022101-001	NUT		1				
131	021101-027	FLAT WASHER		1				
132	050012-000	BEARING		1				
133	224042-000	LOWER ARM		1				
134	053014-000	BEARING FLANGE		1				
135	028935-001	SET SCREW		1				
136	021202-003	SPRING WASHER		1				
137	022101-001	NUT		1				
138	290077-000	ARM PIN		1				
139	053014-000	BEARING FLANGE		1				
140	053014-000	BEARING FLANGE		1				
141	270251-000	CONNECTOR		1				
142	028935-001	SET SCREW		1				
143	021202-003	SPRING WASHER		1				
144	022101-001	NUT		1				
145	224041-000	UPPER ARM		1				
146	290077-000	ARM PIN		1				
147	053014-000	BEARING FLANGE		1				
148	914019-000	SPONGE		1				
149	020127-003	SCREW		2				
150	090042-000	SWITCH		1				
151	020216-005	SCREW		2				
152	990026-004	MOTOR		1				
D10		INC. 22-24,27,28,40-42,149						
A02	040026-001	BLADE CHANGING ROD		1				
A03	040005-003	HEX WRENCH "L" M3		1				
A04	040006-001	HEX WRENCH "L" M4		1				